



Configuration of computer to use GmPRS using Thuraya 2510 as modem in Windows XP

Your SIM card has to be provisioned with the GmPRS service, please contact info@satellitecommunication.ch to confirm this service if unsure.

To define your phone as a modem:

1. Please download the latest upgrade software and firmware from SatCom's web site at <http://www.satcomgroup.com/support/?article=695>
2. When the main menu appears, click "Thuraya SO-2510 Upgrader".
3. Click "Next".
4. The drivers will now install. Click "Finish" to complete.
5. Remove the rubber grommet from the bottom of the handset and attach the USB cable.
6. Insert a SIM card into the phone and power the handset on.
7. Attach the USB cable to your computer.
8. Click next when the "Add new hardware" wizard appears. If prompted, choose continue anyway on the Windows Logo testing screen.
9. Repeat step 8 for all APsi hardware that appears.
10. Press exit on the main menu screen when complete.

To create the dial-up connection:

11. Click Start→Settings→Control Panel.
12. Double click on "Network Connections".
13. Click on "Create a New Connection" on the left-hand side.
14. Choose Connect Directly to the Internet.
15. Choose to setup your connection manually.
16. Choose "Connect using a dial-up modem".
17. Choose the "Thuraya 2510 USB SAT modem" that you created earlier
18. Type in an ISP name (This can be anything).
19. Type in the phone number that you want to dial. For Thuraya GmPRS Internet, type *99#
20. Type in the username and password for your connection. For Thuraya GmPRS Internet, the username and password must be blank.
21. Click "Finish" to create your connection.
22. To dial the connection, double click on the icon in Network Connections and choose "Dial".