



THURAYA – procedure to setting up Emails using SG-2520

Please note if you are going to use your own email server POP and SMTP please check with your email service provider that the account supports SMTP authorisation.

GmPRS also needs to be activated on the SIM account

1. Power the phone up and select Menu > Messaging Settings > Email
2. Press the left hand key above the Green answer key to select Options.
3. Using the scroll keys press the down key and select Mailbox List.
4. Press options New > Select
5. Enter the Title: (this can be anything)
6. Enter your name: (this can be anything)
7. Enter your email address:
8. Server type "POP3"
9. Incoming server: (POP) e.g. pop.mailserver.com
10. Port 110
11. User ID: your login details to the mail server
12. Password: password for the mail server
13. Copy on server: Please select this option as if this option is not selected the email will be downloaded to the phone and not left on the server.
14. Outgoing server: (SMTP) e.g. smtp.mailserver.com
15. Port 25
16. Access Point: ThurayaGmPRS (please use the scroll keys to select this options)
17. Once the credentials have been inputted select Options > Done
18. Press close and return to the Email setup screen.
19. Make sure that the Current mailbox is selected to the mailbox you have just created. Scroll through the options and select how you wish to the mail to be downloaded.
(Please consult your IT department if you are unsure with this step)
20. Please now select Options > Done to save changes

To receive email please follows the below

- 1) Menu > Messaging > Inbox
- 2) Scroll to the third icon of a Global with an e in the centre.
- 3) Press options and scroll to Receive mail
- 4) Please wait for the messages to download