



www.**satellite**-telephone.ch

PUK deblocage – on IRIDIUM 9505A

enter ****05***

press

enter your PUK **was provided with the SIM-card**

press

Enter your pin code xxxx (default 1111) confirm pin xxxx